


# Harlequin's Professional Freestanding Ballet Barre Assembly Instructions



Your Harlequin Professional Freestanding Ballet Barre will arrive in five sections:

1. 1 x top section with two beach or aluminium bars
2. 2 x upright sections
3. 2 x foot sections
4. 1 x Allen key



1. Insert upright sections into foot sections on both sides.



2. Tighten the hex screws with the Allen/hex key provided.



3. Insert the connected upright and foot sections into each end of the top section.



4. Tighten the hex screws with the Allen/hex key provided.



N.B The feet on the foot sections are adjustable for stability on an uneven floor. Adjust with a spanner as required (spanner not included).

If you would like further information and advice, please contact us on +852 254 11 666 or [hksales@harlequinfloors.com](mailto:hksales@harlequinfloors.com)



**HARLEQUIN**  
[www.harlequinfloors.com](http://www.harlequinfloors.com)